

Please read all instructions before beginning.

## General Instructions

This very popular valance treatment can be used on any window up to 56". Using this treatment on windows over 56" may cause the bottom rod to sag. The projections for the pattern are 8", 10", and 12". The length of the valance from the mounting board to the bottom of the pleat is 14", 15 ½", and 17 ½" respectively and the drop in the front is about 5" before any cutouts. Any shape can be used on the end of the drop to create interest. Some examples are listed in the instructions.

Windows will need to have the fabric pieced and matched as follows:

Wider than 28" for the 12" projection

Wider than 32" for the 10" projection

Wider than 36" for the 8" projection

When laying out the pattern on your fabric, be sure to center any design or stripe.

## Fabric Suggestions

Any drapery or light weight upholstery fabric with some body. Thin, soft fabrics are not recommended.. Contrast or self lining may be used if you don't want to see the lining from underneath the valance.

Interlining is recommended to make the treatment hang better.

## Yardage Requirements

<u>Projection</u>	<u>Window Width</u>	
	<u>Up to 36"</u>	<u>36" - 56"</u>
8"	3/4 yds	1 ½ yds
10"	1 yd	1 ¾ yds
12"	1 yd	1 ¾ yds

\*Note: For extra large prints allow extra fabric.

## Trim Calculation

To calculate trim add:

22" + width of window for 8" projection.

26" + width of window for 10" projection

30" + width of window for 12" projection

\*Note: If you have a shaped design on the bottom of your valance allow extra trim.

## Materials Needed

Temporary Fabric Marker

Large Straight Edge

½" PVC Pipe

½" PVC Elbows

1" x 1" Board